

FINE PORCELAIN






RAK
PORCELAIN

Fine Porcelain



*A collection that speaks without shouting.
Matte surfaces, deep tones, and a presence that lingers
in silence. Strength and elegance, expressed through restraint.*


Quiet Boldness.





Two-zones plate

Zwei-Zonen-Teller
Assiette double zones
Piatto a due zone
Plato de dos zonas




25 cm – 9.84"
📦 12

- FPFISOV2ZDH25MH
- FPFISOV2ZDH25OV
- FPFISOV2ZDH25SS
- FPFISOV2ZDH25SC
- FPFISOV2ZDH25PT

Round plate with relief

Runder teller mit Relief
Assiette ronde à relief
Plato redondo con relieve
Piatto rotondo con rilievo



30 cm – 11.81"
📦 6

- FPFSCRPT2Z30MH
- FPFSCRPT2Z30OV
- FPFSCRPT2Z30SS
- FPFSCRPT2Z30SC
- FPFSCRPT2Z30PT

Rectangular plate with relief

Teller rechteckig mit Relief
Assiette rectangulaire à relief
Plato rectangular con relieve
Piatto rettangolare con rilievo



35 cm – 13.78"
📦 6

- FPFSSRPT2Z35MH
- FPFSSRPT2Z35OV
- FPFSSRPT2Z35SS
- FPFSSRPT2Z35SC
- FPFSSRPT2Z35PT

Square platter with relief

Teller quadratisch mit Relief
Assiette carrée à relief
Plato cuadrado con relieve
Piatto quadrato con rilievo



30 cm – 11.81"
📦 6

- FPFSSQPT2Z30MH
- FPFSSQPT2Z30OV
- FPFSSQPT2Z30SS
- FPFSSQPT2Z30SC
- FPFSSQPT2Z30PT



Dish with handle

Geschirr mit griff

Plat avec anse

Plato con asa

Piatto con manico



24 cm – 9.45"
📦 12

● FPFSBTDH24MH

● FPFSBTDH24SS

● FPFSBTDH24OV

● FPFSBTDH24PT

● FPFSBTDH24SC

18 cm – 7.09"
📦 12

● FPFSBTDH18MH

● FPFSBTDH18SS

● FPFSBTDH18OV

● FPFSBTDH18PT

● FPFSBTDH18SC

14 cm – 5.51"
📦 12

● FPFSBTDH14MH

● FPFSBTDH14SS

● FPFSBTDH14OV

● FPFSBTDH14PT

● FPFSBTDH14SC





*Designed
to stand out*



Boat plate

Bootsteller
Assiette bateau
Plato barco
Piatto a forma di barca



40 cm – 15.75"
📦 12

● FPFSBTOP40SS
● FPFSBTOP40PT

● FPFSBTOP40OV
● FPFSBTOP40SC

● FPFSBTOP40MH

32 cm – 12.6"
📦 12

● FPFSBTOP32SS
● FPFSBTOP32PT

● FPFSBTOP32OV
● FPFSBTOP32SC

● FPFSBTOP32MH

24 cm – 9.45"
📦 12

● FPFSBTOP24SS
● FPFSBTOP24PT

● FPFSBTOP24OV
● FPFSBTOP24SC

● FPFSBTOP24MH

Bowl

Schale
Bol
Bol
Coppetta



22 cm – 8.66"
📦 12

● FPFSBTBW22SS
● FPFSBTBW22PT

● FPFSBTBW22OV
● FPFSBTBW22SC

● FPFSBTBW22MH

15 cm – 5.91"
📦 12

● FPFSBTBW15SS
● FPFSBTBW15PT

● FPFSBTBW15OV
● FPFSBTBW15SC

● FPFSBTBW15MH




Deep plate

Teller tief

Assiette creuse

Plato hondo

Piatto fondo



30 cm – 11.81"

📦 6

● FPFSBBDP30MH

● FPFSBBDP30PT

● FPFSBBDP30SC

● FPFSBBDP30SS


● FPFSBBDP30OV





Boat cocotte flat with handles

Bootförmige, flach Cocotte mit Henkel
Cocotte bateau plate avec poignées
Cocotte barco plana con asas
Cocotte barca piatta con maniglie




26 cm – 10.24"
6

- FPFSBTOF26PT
- FPFSBTOF26OV
- FPFSBTOF26SS
- FPFSBTOF26SC
- FPFSBTOF26MH

Boat cocotte deep with handles

Bootförmige, tiefe Cocotte mit Henkel
Cocotte bateau profonde avec poignées
Cocotte barco profunda con asas
Cocotte barca profonda con maniglie



26 cm – 10.24"
6

- FPFSBCOD26PT
- FPFSBCOD26OV
- FPFSBCOD26SS
- FPFSBCOD26SC
- FPFSBCOD26MH

Winged dish

Flügelteller
Plat à ailes
Plato con alas
Piatto con ali



20 cm – 7.87"
12

- FPFSWGDH20PT
- FPFSWGDH20OV
- FPFSWGDH20SS
- FPFSWGDH20SC
- FPFSWGDH20MH

Dish with two handles

Schale mit zwei Griffen
Plat avec deux anses
Plato con dos asas
Piatto con due manici



30 cm – 11.81"
12

- FPFSBDH30H2PT
- FPFSBDH30H2OV
- FPFSBDH30H2SS
- FPFSBDH30H2SC
- FPFSBDH30H2MH



*Boldness in
every detail.*





Large plate

Großer teller
Grande assiette
Plato grande
Piatto grande




32 cm – 12.6"
📦 6

- FPFSBBSP32SS
- FPFSBBSP32PT
- FPFSBBSP32MH
- FPFSBBSP32OV
- FPFSBBSP32SC

Saucer

Untertasse
Soucoupe
Platillo
Piattino



13 cm – 5.12"
📦 24

- FPFSBBSA13SS
- FPFSBBSA13PT
- FPFSBBSA13MH
- FPFSBBSA13OV
- FPFSBBSA13SC

Cloche

Cloche
Cloche
Campana
Coperchio



18 cm – 7.09"
📦 2

- FPFSBBCH18SS
- FPFSBBCH18PT
- FPFSBBCH18MH
- FPFSBBCH18OV
- FPFSBBCH18SC

Saucer two indent

Untertasse Zwei Vertiefungen
Soucoupe double zones
Platillo con dos cavidades
Piattino due incavi



27 cm x 15 cm
10.63" x 5.9"
📦 12

- FPFSBBSA2IN27SS
- FPFSBBSA2IN27PT
- FPFSBBSA2IN27MH
- FPFSBBSA2IN27OV
- FPFSBBSA2IN27SC



Jug
 Krug
 Carafe
 Jarra
 Caraffa



30 cl – 10.14 oz
 12

● FPFSJG30OV

● FPFSJG30MH
 ● FPFSJG30SC

● FPFSJG30SS
 ● FPFSJG30PT

15 cl – 5.07 oz
 12

● FPFSJG15OV

● FPFSJG15MH
 ● FPFSJG15SC

● FPFSJG15SS
 ● FPFSJG15PT


09 cl – 3.05 oz
 12

● FPFSJG09OV

● FPFSJG09MH
 ● FPFSJG09SC

● FPFSJG09SS
 ● FPFSJG09PT

Plate three zones
 Teller Drei Zonen
 Assiette trois zones
 Plato tres zonas
 Piatto a tre zone




29 cm x 25cm
 11.42" x 9.84"
 12

● FPFSBBOP3IN29OV
 ● FPFSBBOP3IN29MH
 ● FPFSBBOP3IN29SC

● FPFSBBOP3IN29SS
 ● FPFSBBOP3IN29PT

Plate two zones
 Zwei-Zonen-Teller
 Assiette deux zones
 Plato dos zonas
 Piatto due zone



22 cm x 25,5cm
 8.66" x 10,04"
 12

● FPFSBBOP2IN25OV
 ● FPFSBBOP2IN25MH
 ● FPFSBBOP2IN25SC

● FPFSBBOP2IN25SS
 ● FPFSBBOP2IN25PT

Double bowl

Doppelschale
Bol double
Bol doble
Coppetta doppia



18 cm x 8.5 cm
7.09" x 3.35"
📦 6

● FPFSBDBW2LN18SS ● FPFSBDBW2LN18OV ● FPFSBDBW2LN18PT
● FPFSBDBW2LN18SC ● FPFSBDBW2LN18MH

Triple bowl

Dreierschale
Bol triple
Bol triple
Ciotola tripla



21 cm x 7cm
8.27" x 2.76"
📦 12

● FPFSBBBW3LN21SS ● FPFSBBBW3LN21OV ● FPFSBBBW3LN21PT
● FPFSBBBW3LN21SC ● FPFSBBBW3LN21MH









Asymmetric plate
 Asymmetrischer Teller
 Assiette asymétrique
 Plato asimétrico
 Piatto asimmetrico



30 cm – 11.81"
 6

● FPFASASP30SC

● FPFASASP30SS

● FPFASASP30PT

● FPFASASP30OV

● FPFASASP30MH



25 cm – 9.84"
 12


● FPFASASP25SC

● FPFASASP25SS

● FPFASASP25PT

● FPFASASP25OV

● FPFASASP25MH



21 cm – 8.27"
 12

● FPFASASP21SC

● FPFASASP21SS

● FPFASASP21PT

● FPFASASP21OV

● FPFASASP21MH

Asymmetric plate two zones

Asymmetrischer Teller zwei Zonen

Assiette asymétrique deux zones

Plato asimétrico dos zonas

Piatto asimmetrico due zone



30 cm – 11.81"

📦 6

● FPFASASP2Z30MH

● FPFASASP2Z30SC

● FPFASASP2Z30SS

● FPFASASP2Z30OV

● FPFASASP2Z30PT



20 cm – 7.87"

📦 12

🍷 BCFSCU10M

● FPFASASP2Z20MH

● FPFASASP2Z20SC

● FPFASASP2Z20SS

● FPFASASP2Z20OV

● FPFASASP2Z20PT


Asymmetric plate three zones

Asymmetrischer Teller drei Zonen

Assiette asymétrique trois zones

Plato asimétrico tres zonas

Piatto asimmetrico tre zone



21 cm – 8.27"

📦 12

● FPFASASP3Z21MH

● FPFASASP3Z21SS

● FPFASASP3Z21SC

● FPFASASP3Z21OV

● FPFASASP3Z21PT


Asymmetric deep plate

Asymmetrischer tiefer Teller

Assiette creuse asymétrique

Plato hondo asimétrico

Piatto profondo asimmetrico



27 cm – 10.63"

📦 12

● FPFASADP27MH

● FPFASADP27SS

● FPFASADP27SC

● FPFASADP27OV

● FPFASADP27PT



*Where color
finds its quiet
strength*







Sugar Bowl & lid

Zuckerdose & Deckel
Sucrier & couvercle
Azucarero & tapa
Zuccheriera & coperchio



20 cl – 6.76 oz
📦 12

- FPFSSB20OV
- FPFSSB20PT
- FPFSSB20MH
- FPFSSB20SS
- FPFSSB20SC

Gourmet deep plate

Gourmetschale tief
Assiette creuse gourmet
Plato hondo gourmet
Piatto fondo gourmet




25 cm – 9.84"
📦 6

- FPF SRDDH25OV
- FPF SRDDH25PT
- FPF SRDDH25MH
- FPF SRDDH25SC
- FPF SRDDH25SS

Oval gourmet deep plate

Ovaler Gourmetschale tief
Assiette creuse gourmet ovale
Plato hondo ovalado gourmet
Piatto fondo ovale gourmet



28 cm – 11.02"
📦 6

- FPF SOVDH28OV
- FPF SOVDH28PT
- FPF SOVDH28MH
- FPF SOVDH28SC
- FPF SOVDH28SS



Tea Pot
Teekanne
Théière
Tetera
Teiera



40 cl – 13.53 oz
📦 4

● FPFSTP40OV
● FPFSTP40PT
● FPFSTP40MH

● FPFSTP40SC
● FPFSTP40SS





Coffee cup

Kaffeetasse
Tasse à café
Taza a café
Tazza da caffè



16 cl – 5.4 oz
📦 12

- FPFSCU16SS
- FPFSCU16PT
- FPFSCU16MH
- FPFSCU16OV
- FPFSCU16SC

Espresso cup

Espressotasse
Tasse à expresso
Taza a expreso
Tazza da espresso



9 cl – 3.04 oz
📦 12

- FPFSCU09SS
- FPFSCU09PT
- FPFSCU09MH
- FPFSCU09OV
- FPFSCU09SC

Coffee Pot

Kaffeekanne
Cafetière
Cafetera
Caffettiera



50 cl – 16,91 oz
📦 4

- FPFSCP50SS
- FPFSCP50PT
- FPFSCP50MH
- FPFSCP50OV
- FPFSCP50SC

Coffee Cup Without Handle

Tasse ohne Henkel
Tasse sans anse
Taza sin asa
Tazza senza manici



10 cl – 3.38 oz
📦 12

- FPFSCU10MSS
- FPFSCU10MPT
- FPFSCU10MMH
- FPFSCU10MOV
- FPFSCU10MSC







Gourmet deep plate

Gourmet teller tief
Assiette creuse gourmet
Plato hondo gourmet
Piatto fondo gourmet




29 cm – 11.4"
161 cl – 54.4 oz
📦 6

- FPSPGD29SS
- FPSPGD29PT
- FPSPGD29OV
- FPSPGD29MH
- FPSPGD29SC

Oval platter

Platten oval
Plat oval
Fuente ovale
Piatto ovale



33.5 cm x 25 cm
13.2" x 9.8"
📦 12

- FPSPOP34SS
- FPSPOP34PT
- FPSPOP34OV
- FPSPOP34MH
- FPSPOP34SC

Round deep coupe plate

Teller tief coup rund
Assiette creuse coupe ronde
Plato hondo coupe redondo
Piatto fondo rotondo senza falda



26.5 cm – 10.4"
156 cl – 53 oz
📦 12

- FPSPDC27SS
- FPSPDC27PT
- FPSPDC27OV
- FPSPDC27MH
- FPSPDC27SC

Round flat coupe plate

Teller flach coup rund
Assiette plate coupe ronde
Plato llano coupe redondo
Piatto piano rotondo senza falda



24 cm – 9.5"
📦 12

- FPSPCP24SS
- FPSPCP24PT
- FPSPCP24OV
- FPSPCP24MH
- FPSPCP24SC

Round flat plate with rim

Teller flach rund mit Rand
Assiette plate ronde à aile
Plato llano redondo con ala
Piatto piano rotondo con falda




29 cm – 11.4"

📦 12

- FPSPFP29SS
- FPSPFP29PT
- FPSPFP29OV
- FPSPFP29MH
- FPSPFP29SC

Round deep plate with rim

Teller tief rund mit Rand
Assiette creuse ronde à aile
Plato hondo redondo con ala
Piatto fondo rotondo con falda



28 cm – 11"

63 cl – 21oz

📦 12

- FPSPDRP28SS
- FPSPDRP28PT
- FPSPDRP28OV
- FPSPDRP28MH
- FPSPDRP28SC





Coffee / tea cup

Kaffee- / Teetasse
Tasse à café / thé
Taza a café / té
Tazza da caffè / tè




6 cm – 24 cl
2.44" – 8 oz
📦 12

- FPSPCU23PT
- FPSPCU23SS
- FPSPCU23OV
- FPSPCU23MH
- FPSPCU23SC

Sugar bowl & lid

Zuckerdose & Deckel
Sucrier & couvercle
Azucarero & tapa
Zuccheriera & coperchio



7 cm – 28 cl
2.83" – 9.5 oz
📦 6

- FPSPSU22PT
- FPSPSU22SS
- FPSPSU22OV
- FPSPSU22MH
- FPSPSU22SC

Saucers for coffee / tea cups

Untere für Kaffee- / Teetassen
Soucoupes pour tasses à café / thé
Platillos para tazas a café / té
Piattini per tazze da caffè / tè



17.5 cm – 6.89"
📦 12

- FPSPSA17PT
- FPSPSA17SS
- FPSPSA17OV
- FPSPSA17MH
- FPSPSA17SC



15 cm – 5.91"
📦 12

- FPSPSA15PT
- FPSPSA15SS
- FPSPSA15OV
- FPSPSA15MH
- FPSPSA15SC

Product care

Fine Porcelain by RAK is crafted for durability, safety, and long-term use. Proper care helps extend its lifespan and minimizes breakage.

Washing Tips :

- Rinse items promptly after use.
- Remove food residues using rubber tools or a water spray.
- Observe water temperatures :
 - Pre-wash: 43–60°C
 - Wash: 65–70°C
- Do not overload dishwasher racks.
- Place items securely in designated slots to prevent movement during washing.

Storage Tips :

- Allow dishes to dry and cool before stacking.
- Stack only same-size items, up to a maximum height of 30 cm.
- Use plastic-coated racks to avoid direct contact between pieces.
- Store cups and hollowware in proper racks.
- Keep porcelain, metal, and glass items separated.

Avoid :

- Letting dirty dishes accumulate.
- Stacking items that are hot, wet, or mismatched.
- Using metal trays or abrasive cleaning pads.
- Scraping with metal utensils.
- Overcrowding washing or storage areas.
- Storing items in corridors or high-traffic zones.

Best Practices :

- Train staff regularly and use visual reminders.
- Monitor breakage and analyze causes.
- Maintain sufficient stock to avoid overuse.
- Reward teams for maintaining low breakage rates.

Heat Use :

- Safe for use in plate warmers and under salamander grills.
- Not oven safe.



By following these guidelines, you will **extend the lifespan of your items** while preserving their beauty and strength. Proper care and handling not only minimize the risk of breakage but **also ensure optimal performance in daily service**. The quality and durability of your products depend **on consistent best practices**.





Special thanks to the following chefs

Alexis Julien & Corentin Martin

Photos credits : Shine Luxembourg
Concept and graphic design by RAK
Printed by

RAK_catalogue_FINEPORCELAIN_01_110925



© RAK Porcelain 2024

RAK Porcelain LLC
P.O. Box - 30113 - Ras Al Khaimah
United Arab Emirates
T +971 7 223 8905
F +971 7 223 8311
rakporcelain@rakporcelain.com

RAK Porcelain Europe S.A.
440, Z.A.E. Wolser F
L-3290 Bettembourg - Luxembourg
T (+352) 26 36 06 65
F (+352) 26 36 04 65
info@rakporcelaineurope.com

RAK Porcelain USA Inc
251 Solar Drive, Suite 1000
Imperial, PA 15126
USA
T +1 (866)-552-6980
info@rakporcelainusa.com

Join us!



www.rakporcelain.com

|MAKE SURE IT'S RAK|